

TECHNICAL INFORMATION



PRODUCT
P 1 / 14


Models No. ▶ AN250HC

Description ▶ Pneumatic Concrete Nailer

CONCEPT AND MAIN APPLICATIONS

Model AN250HC is a pneumatic concrete nailer powered by high pressure air.

Drives 19 to 25mm (3/4 to 1") long plastic sheet collated concrete pins to fasten metal studs to concrete easily.



Dimensions: mm (")	
Length (L)	295 (11-5/8)
Width 1 (W1)	128 (5)
Width 2 (W2)	88 (3-1/2)
Height (H)	291 (11-1/2)

Width 1: with Hook
Width 2: without Hook

► Specification

Nail	Nail type		Plastic sheet collated concrete pins	
	Nail collation angle		0 degree	
	Shank diameter: mm (")	Length: mm (")	2.5 (0.099) 3.0 (0.120)	19, 22, 25 (3/4, 7/8, 1) 19 (3/4)
Magazine capacity		100 pins		
Operating air pressure: MPa (kgf/cm ²)		1.18 - 2.26 (12 - 23)		
Weight according to EPTA-Procedure 01/2003: kg (lbs)		2.1 (4.7)		

► Standard equipment

- Hook 1
- Safety goggles 1
- Oil supply (containing 30ml of turbine oil) 1
- Nose adapter A 2
- Nose adapter B 2
- Plastic carrying case 1

Note: The standard equipment for the tool shown above may vary by country.

► Optional accessories

- Plastic sheet collated concrete pins
- Air hoses, etc.
- Air leak repair set

► **Repair**

CAUTION: Repair the machine in accordance with “Instruction manual” or “Safety instructions”.

[1] NECESSARY REPAIRING TOOLS

Code No.	Description	Use for
1R229	1/4” Hex shank bit for M5	Removing / screwing M5 Hex socket head bolt
1R230	1/4” Hex shank bit for M6	Removing / screwing M6 Hex socket head bolt from / to Top cap
1R231	1/4” Hex shank bit for M8	Removing / screwing M8 Hex socket head bolt from / to Driver guide
1R266	Spring pin extractor 2	Removing / driving Spring pin 2 from / to Trigger and Adjuster section
1R268	Spring pin extractor 3	Removing / driving Spring pin 3 from / to Trigger base section
1R291	Retaining ring S and R pliers	Removing / installing Retaining ring R-24

[2] LUBRICATIONS

Apply Isoflex NB52 to the following portions to protect parts and product from unusual abrasion.

Fig. 1


Item No.	Description	Item No.	Description	Item No.	Description
⑤	O ring 60	⑳	O-ring 6	⑩②	O ring 18
⑥	O ring 50	③①	O ring 5	⑩④	O-ring 7 (2pcs.)
⑧	O ring 53	③④	O ring 36	⑩⑥	O-ring 12.5
⑪	O ring 67	⑦⑦	O ring 9	⑩⑧	O ring 3
⑫	O-ring 26	⑦⑨	O ring 14	⑩⑩	O-ring 3 (2pcs.)
⑰	O ring 53	⑩①	O-ring 15	⑩①	O ring 18
⑱	O-ring 39				

Note: O ring 3 is different from O-ring 3.

► **Repair**

[3] FASTENING TORQUE

Tighten the bolts and screws to the following fastening torque.

Note: Apply Loctite 242 or ThreeBond 1321 / 1342 to the bolts designated with hexagonal marks. 

Bind thread sealant tape to One touch joint H22PM designated with flag mark. 












Item No.	Description	Q'ty	Use for	Torque (N.m)
 1	M6x30 Hex socket head bolt	4	Fastening Top cap to Housing set	9.0 - 13.0
 32	M8x30 Hex socket head bolt	4	Fastening Driver guide to Housing set	20.0 - 30.0
 35	Inlet cap	1	Fastening to Housing set	20.0 - 30.0
 37	One touch joint H22PM	1	Fastening to  35 Inlet cap	20.0 - 30.0
 42	M5x30 Hex socket head bolt	1	Fastening Magazine, Housing set and Hook base with Sleeve 5 to M5 Hex nut	2.0 - 3.0
 44	M5x20 Hex socket head bolt	1	Fastening Contact arm cover to Driver guide	2.0 - 3.0
 63	M5x22 Pan head screw	1	Fastening Hook to Hook base	2.0 - 3.0
 92	M4x10 Hex socket head bolt	1	Fastening Lock lever and Lock pin to Door	3.0 - 5.0
 93	M5x12 Hex socket head bolt	1	Fastening Holder to Driver guide	5.0 - 6.5

Fig. 2



► Repair


[4] ASSEMBLING/ DISASSEMBLING

[4]-1. Head valve section

DISASSEMBLING


(1) Disassemble Top cap from Housing set as illustrated in **Fig. 3**.

Fig. 3



(2) Disassemble Rear cushion from Top cap as illustrated in **Fig. 4**.


Fig. 4



ASSEMBLING

- 1) Assemble Rear cushion to Top cap.
- 2) Put nine Compression springs 4 into holes of Top cap complete.
- 3) Fit Head valve into Top cap complete carefully so as not to lean any Compression springs 4. (**Fig. 5**)

Fig. 5



► **Repair**


[4] DISASSEMBLY/ASSEMBLY

[4]-2. Driver, Cylinder section (Cylinder stay, Valve seat)

DISASSEMBLING


(1) Driver and Cylinder section can be removed as illustrated in **Fig. 6**.

Fig. 6




(2) Remove Cylinder stay and Valve seat from Cylinder as illustrated in **Fig. 7**.

Fig. 7



(3) O rings of Cylinder section can be replaced as illustrated in **Fig. 8**.

Fig. 8



ASSEMBLING

Take the disassembling step in reverse. Refer to **Figs. 8, 7 and 6**.

► **Repair**

[4] DISASSEMBLY/ASSEMBLY


[4]-3. Trigger valve section

DISASSEMBLING

Note: Trigger valve section can be replaced without removing Magazine section and Driver guide from Housing set.

(1) Remove Contact arm and Holder as illustrated in **Fig. 9**.

Fig. 9



(2) Trigger valve section can be disassembled as illustrated in **Figs. 10 and 11**.

Fig.10





Fig. 11



► Repair

[4] DISASSEMBLY/ASSEMBLY

[4]-3. Trigger valve section (cont.)

ASSEMBLING

Refer to the previous page and take the disassembling step in reverse.

Note: • Trigger valve case and Trigger guide have to be firmly inserted into places until the click sounds can be heard.

- Set Change rod in place so that the center protrusion faces outside, and then insert Trigger base section into the groove of Housing set. (Fig. 12)
- Do not fail two different length pins to set in place as illustrated in Fig. 13.
- After setting 1R268 instead of Spring pins 3-20/ 3-32 temporarily, push out 1R268 to set Spring pins 3-20/ 3-32 in places. (Fig. 14)

Fig. 12




Fig. 13





Fig. 14



[4]-4. Trigger assembly

DISASSEMBLING

(1) Remove Contact arm and Holder. (Fig. 9)

(2) Remove two Spring pins 3-32 for securing Trigger assembly. (Fig. 10)

Trigger assembly can be disassembled from Housing set together with Adjuster assy.

Separate Adjuster assy from Trigger assembly. (Fig. 15)

(3) Trigger assembly is disassembled as illustrated in Fig. 16.

Fig. 15





Fig. 16



► Repair


[4] DISASSEMBLY/ASSEMBLY

[4]-4. Trigger assembly (cont.)

ASSEMBLING


- (1) Set the following parts in place as illustrated in **Fig. 17**.
 Torsion spring 5 Stopper plate Torsion spring 6 Lever

Fig. 17



- (2) Mount the above part to Trigger base. (**Fig. 18**)

Fig. 18



- (3) Assemble the Trigger base section to Housing set. (**Figs. 15, 14 and 12**)

► Repair

[4] DISASSEMBLY/ASSEMBLY

[4]-5. Adjuster assy

DISASSEMBLING

Disconnect Contact arm from Slide plate of Adjuster assy, and then remove Holder that secures Adjuster assy to Driver guide.

Remove Contact arm and Holder as illustrated in **Fig. 9**.

Adjuster assy can be disassembled without removing Spring pins 3-20 and 3-32. (**Figs. 19 and 20**)

Fig. 19





Fig. 20



ASSEMBLING

Take the disassembling step in reverse as follows;

- (1) Assemble Adjuster piece to Upper yoke.
- (2) Turn Adjuster piece 90° right in Upper yoke so that Adjuster shaft can be in Adjuster piece.
- (3) Assemble Compression spring 2 and Steel ball 2.3 to Upper yoke. Install Adjuster shaft into Adjuster piece carefully so as not to lose Steel ball 2.3 and Compression spring 2.
- (4) Assemble Spring pin 2-14.
Mount Adjuster assy to Housing set.
- (5) Secure Adjuster assy to Driver guide with Holder and M5x12 Hex socket head bolt.

► Repair


[4] DISASSEMBLY/ASSEMBLY

[4]-6. Front cushion

DISASSEMBLING

- (1) Remove Contact arm cover by unscrewing M5x20 Hex socket head bolt, and remove Urethane ring 3 from Contact arm. See the **center** and **left** illustration in **Fig. 9**. Contact arm can be removed.
- (2) Disassemble Driver guide as illustrated in **Fig. 21**.

Fig. 21



ASSEMBLING


Take the disassembling step in reverse.

[4]-7. Driver guide section, Feeding mechanism

DISASSEMBLING

- (1) Remove Contact arm cover by unscrewing M5x20 Hex socket head bolt, then remove Urethane ring 3 from Contact arm. See the **center** and **left** illustration in **Fig. 9**. Contact arm can be removed.
- (2) Disassemble Driver guide as illustrated in **Fig. 21**.
- (3) Disassemble Door from Driver guide as illustrated in **Fig. 22**.

Fig. 22



► **Repair**

[4] DISASSEMBLY/ASSEMBLY

[4]-7. Driver guide section, Feeding mechanism (cont.)

DISASSEMBLING

(4) Disassemble Feeding mechanism as illustrated in **Figs. 23 and 24**.

Fig. 23





Fig. 24



► **Repair**

[4] DISASSEMBLY/ASSEMBLY

[4]-7. Driver guide section, Feeding mechanism (cont.)

ASSEMBLING

- (1) Assemble O ring 14 to Piston (for Nail feeding), and mount O ring 9 to the cylinder portion of Driver guide. Refer to **Fig. 24**.
- (2) Assemble Feeding claw and Piston as illustrated in **Figs. 25 and 26**.

Fig. 25





Fig. 26



► **Repair**


[4] DISASSEMBLY/ASSEMBLY

[4]-8. Magazine, Magazine cap

DISASSEMBLING

Disassemble Magazine section as illustrated in **Fig. 27**.

Fig. 27



ASSEMBLING


Take the disassembling step in reverse.

[4]-9. Door

DISASSEMBLING

- (1) Remove Pin 5 and Urethane ring 3. Separate Door from Driver guide as illustrated in **Fig. 22**.
- (2) Disassemble Door section as illustrated in **Fig. 28**.

Fig. 28



ASSEMBLING

Take the disassembling step in reverse.

► Repair

[4] DISASSEMBLY/ASSEMBLY

[4]-10. Inlet cap, One touch Joint H22PM

DISASSEMBLING

Inlet cap and One touch joint can be disassembled as illustrated in **Fig. 29**.

If it is difficult to remove One touch joint H22PM as illustrated in **Fig. 29**, One touch joint can be disassembled as illustrated in **Fig. 29A**.

Note: One touch joint H22PM and Inlet cap as Makita high pressure air tool have left handed threads.

Fig. 29




Fig. 29A

